

TPMS RETRO FIT KIT

Protect your classic ride, or any other vehicle that doesn't have a factory installed tire pressure monitoring system!



Plug and Play!

Install the sensors in the assigned positions, plug in the receiver and drive!



♂Off Road Applications

| | TIRE AND LO | |
|--------------|-----------------------------|--------|
| 9 | SEATING CAPACITY | TOTA |
| he comb | ined weight of occupants ar | nd can |
| RE | ORIGINAL SIZE | (|
| ONT | P235/60R17XL | |
| AR | P235/60R17XL | |
| Mark Company | | - |

✓ Tire Pressures that differ from placard



✓ Vehicles without a factory TPMS