

TSB #	SUBJECT	DATE
GI202512-53	Wireless VCI LED Indicator	1/7/2026

Overview:

The Wireless VCI for the 600Pro is equipped with a status indicator LED.

Description:

- **No light** – VCI has no power
 - Check that the VCI is securely inserted in the OBD-II port of a vehicle
 - Check that the vehicle ignition is powered on
- **Flashing red light** – A malfunction has occurred
 - Turn vehicle ignition off
 - Confirm VCI is securely inserted in OBD-II port
 - Turn vehicle ignition on and wait for 5 seconds for fault to clear
- **Solid Red Light** – Wireless VCI is ready to connect
 - Verify that vehicle ignition is on and you are within 15 feet of the VCI
- **Solid Amber Light**- Indicates Wireless VCI is connected to a device
 - Verify you are using the correct VCI
- **Solid Green light** – Indicates connection to vehicle and tool is good.
- **Solid White light** – Indicates connection is loss due to distance. Ensure within 15 feet range

