

TSB #	SUBJECT	DATE
GI202601-75	Toyota Relearn Procedure GEN II	1/20/2026

**Overview:** This document will outline the OBD Relearn on a Toyota or Lexus vehicle using a GEN II Bartec TPMS Tools.

**Process:**

1. Inflate Tires to Placard
2. Using **VINdicate®** or **MMY Listing**, select vehicle
3. Navigate to **Relearn > Relearn: OBD RITE-SYNC®**
4. Following on tool prompts, read all sensor IDs starting at the **LF** tire
5. Following on tool prompts, connect cable or wireless VCI to the vehicles OBDII Port
6. Cycle key/push button to ignition **ON** Engine **OFF**
7. Press **ENTER** on tool to begin writing IDs
  - Tool will begin reading VIN, reading DTCs, and Writing IDs. Please ensure each step is followed by a ✓
8. Once IDs are written, the TPMS light will now be flashing. Leave vehicle in ON position and re-activate sensors starting at the LF tire.
9. Start Engine and verify TPMS light is off.

