



TPMS Technical Service Bulletin



General Information

GI-507-012

Applies To: Removing OBD connector from vehicle and tool

August 13, 2012

Scope of this bulletin:

This bulletin is to inform customer of how to properly remove the OBD cable from the vehicle and tool to refrain from damaging the tool, car, or cable.

Topics covered in this bulletin:

1. How to remove cable from vehicle
2. How to remove cable from tool

1. How to remove cable from vehicle.

When removing the OBD cable from the vehicle it is very important to remove it using the OBD module. Do not remove the OBD connector using the cable, this may damage the Bartec issued OBD cable or the OBD connector on the vehicle. Proper removal is diagramed below.



©2011, Bartec USA - All Rights Reserved

Bartec USA Technical Support: 866-407-8767



TPMS

Technical Service Bulletin



General Information

GI-507-012

2. How to remove cable from tool:

When removing the OBD cable from the tool it is very important to remove it using the 16 prong male connector. Do not remove the OBD connector using the cable, this may damage the Bartec issued OBD cable or the Bartec Tool's 16 prong female connector. Proper removal is diagramed below.

