



TPMS

Technical Service Bulletin



Repair Procedure 

RP-597-012

Applies To: Toyota After Relearn

October 7, 2011

Scope of this bulletin:

After sensor relearns in any Toyota you must activate every sensor to complete the relearn and turn off TPMS light.



Topics covered in this bulletin:

1. Activate Toyota Sensors

1. Setting your tool up

After sensor relearns, if the light is flashing in any Toyota, you must activate every sensor to complete the relearn and turn off TPMS light. The sensor can either be activated with a Bartec tool or by releasing pressure from the tire.