



General Information



TSB #	SUBJECT	
GI-11078-016	Tech 200 Sensor programming positions	
MAKE[S]	MODEL[S]	YEAR[S]
N/A	N/A	N/A
S/W VERSION[S]	TOOL[S] AFFECTED	
Any	Tech 200 & Schrader EZ-Programmer	

Overview

We will be showing you the correct ways in order to place you Tech 200 when doing sensor activation, Test LF activated sensors, or programming a sensor.

Sensor Activation/ Test LF Activated Sensors

To test a sensor the tool should be placed alongside the valve stem and the “Test” key pressed.



Program EZ-Sensor

Free-space:

Place sensor in front of the tool as shown, and follow tool prompts.



or



Inside wheel/tire:

With the sensor in the tire, place the tool with the back on the tire and near the sensor as shown and follow the tool prompts.

